

ATEX/UKEX Installation drawing 9113QA01 V7R0

For safe installation of 9113 the following must be observed. The module shall only be installed by qualified personnel who are familiar with the national and international laws, directives and standards that apply to this area.

Year of manufacture can be taken from the first two digits in the serial number.

If installation in Zone 2 is required, the following must be observed:

The 4501 programming module is to be used solely with PR electronics modules. It is important that the module is undamaged and has not been altered or modified in any way. Only 4501 modules free of dust and moisture shall be installed.

ATEX Certificate: KEMA 07ATEX1148 X
UKEX Certificate: 9113bX - Pending
UKEX Certificate: 9113bX - Pending

Marking 9113bX: I II 1D [Ex d IIC T4 Gc]

Standards: EN 60079-10-2018, EN 60079-11-2012, EN 60079-7-2015+A1-2017

Supply terminal (31.32)

Voltage: 19.2 – 31.2 VDC

Status Relay, terminal (33.34)

Voltage max.: 125VAC / 110VDC

Power max.: 62.5VA / 32W

Current max.: 0.5A AC / 0.3ADC

Specific Conditions of Use

Install in pollution degree 2, overvoltage category II as defined in IEC 60664-1

Do not separate connectors when energized and an explosive gas mixture is present.

Do not connect or disconnect the Power Rail when an explosive gas mixture is present.

Disconnect power before servicing.

The wiring of unused terminals is not allowed.

In type protection (Ex d) the parameters for intrinsic safety for gas group IIb are applicable.

For installation in Zone 2, the module shall be installed in an enclosure in type of protection Ex e, providing a degree of protection of at least IP54. Cable entry devices and blanking elements shall fulfill the same requirements.

For installation on Power Rail in zone 2, only Power Rail type 8400 supplied by Power Control Unit type 9410 (Type Examination Certificate KEMA 07ATEX102 X, DERA 21UEX0169 X) is allowed.

Max. screw terminal torque 0.5 Nm.

Stranded wire should be installed with an insulation stripping length of 5 mm or via a suitable insulated terminal such as a bootstrap fence.

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

4501

9113

Power Rail

Ex Input
CH1 (terminal 41,42,43,44)
CH2 (terminal 51,52,53,54)
U: 8.7 V
I: 18 mA
P: 40 mW
LoRo 892 kHz

C: 50 pF
L: 100 nH

U: 10 V
I: 30 mA
C: 30 nF
L: 800 nH

9113bX Installation:

Hazardous area
Zone 0,1,2, 20, 21, 22

Non Hazardous area
or Zone 2

-20 sTa s +60°C

45